

(Isis Range)



Basin Mixer Chrome



Bidet Mixer Chrome



Basin Mixer (Extended) Chrome



Concealed Shower Mixer Chrome



Concealed Shower Mixer (With Shower-Bath Divertor)




Sink Mixer (Deck Mounted) Chrome



Bath Mixer (Wall Type) with hand shower and Bracket Chrome



Shower Rose
Shower Arm



Bath Spout Chrome



Pop-Up and Waste (Round)



Pop-Up and Waste (Square)

Part Number	Description	Part Number	Description
BP1-1065	Basin Mixer	BP1-1070	Bath Mixer with hand shower & Bracket Chrome Wall Type
BP1-1061	Bidet Mixer Chrome	BP1-SR01	Shower Rose
BP1-1088	Sink Mixer Deck Mounted Chrome	BP1-1602	Shower Arm
BP1-1065E	Basin Mixer Extended Chrome	BP1-6202	Bath Spout Chrome
BP1-1039	Concealed Shower Mixer Chrome	BP1-8027	Pop-Up and Waste (Round)
BP1-1072	Concealed Bath Shower Mixer	BP1-8028	Pop-Up and Waste (Square)

Distributed by

P PENNYWARE
DISTRIBUTORS

To order:
Tel: 011 474 1989
Fax: 011 474 2079
info@pennyware.net
www.pennyware.net

PRO BRASS